


beyerdynamic 

DT 990

- Service Manual -



Ersatzteilliste
Replacement parts
Pièces de rechange

DT 990 PRO

- 95
- 95/ 5
- 95/35R
- 95/40L
- 95/20
- 95/25
- 95/30
- 95/15
- 95/10
- 165
- 135
- 140
- 175
- 170
- 35
- 5 L
- 10 R
- 60
- 45
- 145
- 150
- 155
- 55
- 185
- 130
- 15
- 25
- 40L
- 30R
- 75
- 115
- 110
- 85

K 990.07

